

Resene Colorwood Whitewash

Resene Colorwood Whitewash is an exciting way of achieving a whitewash effect on new timber or old varnished interior timbers.

This product can also be tinted to a greywash effect which can be used on its own or with tinted Resene Colorwood stains for additional greywash options.

interior

Typical uses

- Cork
- Desks
- Doors
- Fibre and particle board
- Furniture
- Panelling
- Parquet
- Skirtings
- Solid timber
- Veneers

Physical properties

Vehicle type	Urethane/acrylic
Pigmentation	Flatting agents
Solvent	Water
Finish	Satin
Colour	Whitewash and greywash
Dry time (minimum)	30 minutes at 18°C
Recoat time (minimum)	2 hours; full cure: 72 hours
Theoretical coverage	About 12 sq. metres per litre
Dry film thickness	23 microns at 12 sq. metres per litre
Usual no. of coats	1; must be overcoated except on previously varnished surfaces
Abrasion resistance	Fair
Heat resistance	Thermoplastic
Solvent resistance	Good
Durability	Good
Thinning and clean up	Water
VOC	95 grams per litre (see Resene VOC Summary)

Performance and limitations

Performance

1. Achieves a stylish whitewash effect on a range of interior timber applications.
2. Low odour application and drying.
3. Water wash up.
4. Easy recoating.
5. An Environmental Choice approved product.

Limitations

1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
2. Dries very quickly at high temperatures and low humidity. Maintain a wet edge.
3. Not recommended for high abrasion areas.
4. Allow 72 hours for coating to reach full cure.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If in doubt contact Resene.



Colorwood Whitewash/Greywash

Surface preparation

New wood

Thoroughly sand surface. Ensure surface is clean and dry, free from dirt, dust and loose material, oil, grease and mould.

Old wood re-varnish

Prepare as for new wood. Ensure surface is clean and dry, free from dirt, dust and loose material, oil, grease and mould. Sand to dull finish with fine sandpaper and remove sanding dust. If old varnish is flaking, everything must be removed to ensure a uniform appearance.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply with a speed brush or synthetic bristle brush (product can be sprayed). Apply evenly to achieve uniform colour. To avoid foaming of material, do not brush excessively. Do not apply in direct sunlight. Resene Colorwood Whitewash/Greywash is designed to be applied and left to cure – do not wipe off.

Allow to dry thoroughly before overcoating. On new timber overcoat with two coats of Resene Aquaclear (see [Data Sheet D59](#)). On flooring overcoat with three coats of Resene Qristal ClearFloor 1K or 2K (see [Data Sheet D506](#) and [D506A](#)). No overcoat required on previously varnished surfaces.

Requires 72 hours for coating to reach full cure. Use stockinged feet on floor prior to full cure.

Precautions

Avoid breathing vapour - use with adequate ventilation.



Colorwood
Whitewash SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 924, Beenleigh, Qld 4207
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.